

VGA Matrix Switcher INSTRUCTION MANUAL



MODEL : AB-4140
4X4 VGA Matrix Switcher

VGA Matrix Switcher Series

Thank you for purchasing the AB-4140 VGA Matrix Switcher. You will find this unit easy to install and highly reliable but it is essential that you read this manual thoroughly before attempting to use this switcher.



SAFETY INFORMATION



1. Save the carton and packing material even if the equipment has arrived in good condition. Should you ever need to ship the unit, use only the original factory packing.
2. Read all documentation before operating your equipment. Retain all documentation for future reference.
3. Follow all instructions printed on unit chassis for proper operation.
4. Do not spill water or other liquids into or on the unit, or operate the unit while standing in liquid.
5. Make sure power outlets conform to the power requirements listed on the back of the unit.
6. Do not use the unit if the electrical power cord is frayed or broken. The power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords and plugs, convenience receptacles, and the point where they exit from the appliance.
7. Always operate the unit with the AC ground wire connected to the electrical system ground. Precautions should be taken so that the means of grounding of a piece of equipment is not defeated.
8. Mains voltage must be correct and the same as that printed on the rear of the unit. Damage caused by connection to improper AC voltage is not covered by any warranty.
9. Power down & disconnect unit from mains voltage before making connections.
10. Never hold a power switch in the "ON" position.
11. Do not use the unit near stoves, heat registers, radiators, or other heat Producing devices.
12. Do not block fan intake or exhaust ports. Do not operate equipment on a surface or in an environment which may impede the normal flow of air around the unit, such as a bed, rug, carpet, or completely enclosed rack. If the unit is used in an extremely dusty or smoky environment, the unit should be periodically "blown free" of foreign matter.
13. Do not remove the cover. Removing the cover will expose you to potentially dangerous voltages. There are no user serviceable parts inside.
14. Do not drive the inputs with a signal level greater than that required to drive equipment to full output.
15. Non-use periods. The power cord of equipment should be unplugged from the outlet when left unused for a long period of time.
16. Service Information Equipment should be serviced by qualifier service personnel when:
 - A. The power supply cord or the plug has been damaged.
 - B. Objects have fallen, or liquid has been spilled into the equipment.
 - C. The equipment has been exposed to rain
 - D. The equipment does not appear to operate normally, or exhibits a marked change in performance
 - E. The equipment has been dropped, or the enclosure damaged.

IMPORTANT SAFETY INSTRUCTIONS

To insure the best from this product, please read this manual carefully. Keep it in a safe place for future reference.

To reduce the risk of electric shock, do not remove the cover from the unit. No user serviceable parts inside. Refer servicing to qualified personnel.

To reduce the risk of fire, do not expose the unit to rain, water or excessive moisture.

Do not force switched or external connections.

When moving the unit disconnect the serial port connections first then the power cable and finally the interconnecting cables to other devices.

Do not attempt to clean the unit with chemical solvents or aerosol cleaners, as this may damage the unit. Use a clean dry cloth.

Installation of this unit should be in a cool dry place, away from sources of excessive heat, vibration, dust, moisture and cold.

INTRODUCTION

INTRODUCTION	3
FEATURES&SPECIFICATIONS	4
FRONT PANEL	5
REAR PANEL	6
REMOTE CONTROL	7
IR EXTENDER	8
RS-232 SERIAL INTERFACE	9
RS-232 PROTOCOL COMMANDS	9
LIMITED WARRANTY	10



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK),
NO USER SERVICEABLE PARTS INSIDE,
REFER SERVICING TO QUALIFIED SERVICE PERSONAL.

WARNING!

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK
DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.



This symbol is intended to alert the user to the presence of non-insulated "dangerous voltage" within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operational and maintenance (servicing) instructions in the literature accompanying the appliance.

To prevent electric shock do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure. To prevent electric shock, match wide blade of plug to wide slot, fully insert.



INTRODUCTION

Congratulations on your purchase of one of the most innovative VGA(RGBHV) 4x4 matrix switching products on the market Today. The AB-4140 is a true Matrix Routing Switcher for VGA(RGBHV) signals.

It has 4 individual VGA(RGBHV) inputs with 4 individual RGBHV outputs. Because it is a matrix router, any input may be routed to any output; or the same input may be routed to all outputs or any combination. It completely eliminates the need to constantly move around VGA video input and output cables.

The AB-4140 is useful for Matrix signals from VGA source devices (such as: Personal computer, Set Top Box, and Satellite Receivers, etc.) To VGA destination devices (Such as LCD Monitors, VGA Monitors, Plasma LCD TV, VGA Projectors, etc.). Selection of inputs is made via the front panel push buttons or an Infrared Remote Control unit or RS-232 control by a computer.

Package Includes:

- (1) AB-4140 4x4 Matrix Switcher
- (2) IR Remote Control
- (3) Rack Mounts
- (4) RS-232 driver CD (All Windows Operating Systems)
- (5) Users Guide
- (6) AC/DC Adapter: 12VDC, 100 ~ 230 VAC
AC/DC Adaptor Types : CE/UL/SAA/BS

Safety Notice!

To prevent damage to your television equipment, use only the supplied AC Adaptor and make the power connections to your television

FEATURES & SPECIFICATIONS

FEATURES


- Supports 4x inputs VGA to 4x VGA outputs Matrix Switcher
- Input signal type VGA (RGBHV)
- Output Signal type VGA to VGA Monitor display
- Higher Video Bandwidth 325MHz each path R,G,B signals.
- Supported HD high definition resolutions XGA, SXGA, UXGA, WSXGA, WUXGA
- RS-232 Serial interface via Ethernet control is optional
- Compatible with all VGA Video Monitor devices, Plasma display and Projectors
- Supported RS-232 serial interface protocol commands list
- Control PC RS-232 Drive compatible with win-95/98/2000/xp
- Various User Interface controls:
 - Attached Window based control software for Desktop or NB control by RS-232 port
 - Manual controlled by Front Panel button
 - IR remote control
- Support desktop with Ear mount and 19 inch Rack mountable type panel
- Power supply DC12Volt, Universal Type Switch 100~230VAC, 50/60Hz

SPECIFICATIONS

- **Type of Switcher:** 4 inputs to 4 outputs VGA Matrix Switcher
- **Video Bandwidth:**
 - 380MHz (-3 dB) 200mV p-p
 - 310MHz (-3 dB) 2V p-p
 - R=325MHz
 - G=325MHz
 - B=325MHz
 - H=110MHz
 - V=110MHz
- **Gain Flatness:** 90 Mhz, .1dB
- **Differential Gain Error:** .01% , .1dB
- **Differential Phase Error:** .02, .1dB (RL-150 Ω)
- **Fast Settling Time:** 15ns to 0.1%
- **All Hostile Crosstalk:** -84 db @ 5 MHz, -54 @ 50 MHz
- **Channel Crosstalk:** -56 db @ 100 Mhz
- **Slew Rate:** 1000V/us, G=+1.2 V Step
- **High OFF Isolation:** -100dB @10MHz
- **Settling Time:** 50ns to 0.1%
- **Output Current:** 100mA
- **Low power CMOS:** 500 uA Quiescent Current
- **Controls:** IR Remote Controller (38KHz), Front panel selection buttons with LED readout
- **Dimensions (WxDxH):** 17.32in x 7.80in x 1.73in (440mm x 200mm x 44mm)
- **Net Weight (Unit Only):** About 3.85 Lbs (with metal case)
- **Safety Approvals:** CE, FCC, RoHS(2002/ 95 / EC)
- **Power Voltage Input:** DC 12V @2A

FRONT PANEL

FRONT PANEL



1. POWER ON SWITCH

The power switch turns the unit on and off. The LED will illuminate red to indicate that the switcher is ON and is receiving power

2. SOURCE DEVICE STATUS LED DISPLAY

Channels 1 to 4 shown from LED display illuminates red to indicate that a video source is present on that input.

3. SOURCE DEVICE SELECT UP BUTTONS

A separate output 1 thru 4 source select buttons are provided for each destination.

4. SOURCES SELECT DOWN BUTTONS

Setup the input sources 1 thru 4 channel.

5. IR SENSOR

The IR sensor receives IR commands from the supplied remote controller.

6. 19 INCH EAR MOUNT PAIR

19 inch 1 RU {1 3/4"} rack mount brackets. Part number: 1U-440L

OPERATING THE UNIT

Once you have connected the switcher as described above, you must be certain that the input are being fed appropriate signals and are not suffering from signal loss due to cabling problems or problems with the source device.

If the input signals to the switcher are appropriate, switch the power switch to <ON> and you should see and hear the signals on the devices you have connected to the various output connectors of the switcher.

POWER AND CONNECTIONS

This unit is not disconnected from the AC power source as long as it is connected to the wall outlet. The off state for this unit is called standby mode. In standby mode the unit is designed to consume a reduced quantity of power compared to normal operating modes.

When it is not using the unit for a long period of time, insure that the AC power cord is disconnected from the wall outlet.

The AC wall outlet should be installed near to the unit and be easily accessible.

Do not plug in or attempt to operate an obviously damaged unit.

BACK PANEL

BACK PANEL



1. DC POWER INLET:

The switcher is fitted with a DC power plug input connector. Please ensure that the plug used is of an approved type and is of sufficient current carrying capacity with the correct voltage and connector polarity. 12Volt DC power supply 1A-2A Max.




Power Jack:

DC Jack - Inner OD Ø 2.1 mm (+)
Outside OD Ø 5.5mm (GND)
Power input -12VDC, 1A-2A
Switcher power supplier use universal
Part number: TA007

2. RS-232 CONNECTION:


RS-232 control port to allow for interfacing to a PC, such as a computer or touch panel control, to the switcher via this DB-9pin Female connector for serial RS-232 control.



Remote port: DB-9pin Female connector

3. INPUTS: 1-4 VGA SOURCES:


Connect a signal source of VGA (RGBHV) device via VGA cable output to 4x VGA Monitor displays.



VGA(RGBHV) Via 1x HD-15p connector
Note: With 1 x female D-Sub connector.

4. OUTPUTS: 1-4 VGA DESTINATIONS:

Connect a signal of VGA via VGA cable output to VGA Monitor displays from 4x VGA input source devices.



VGA(RGBHV) Via 1x HD-15p connector
Note: With 1 x female D-Sub connector.

REMOTE CONTROL

Before making any connections to the AB-4140. Observe the following:

Ensure the mains voltage supply matches the label on the supplied plug- Pack (+/- 10%).

Ensure that the power switch is OFF.

Ensure that all system grounds (earth) are connected to a common point.

Avoid powering equipment within a system from multiple power sources that may be separated by large distances.

Connect all audio video sources and destination equipment.

Power up all source and destination audio-visual sources.

For each destination output select the appropriate input source by using the front panel input 1-4 select buttons. The supplied IR remote control. Or through the RS-232 serial communications port.

Upon power up the switcher will return to its last used setting before Powered down.

REMOTE CONTROL

1. SWITCH POWER ON or OFF:

Controller with a power ON and OFF

2. OUTPUTS: 1 - 4 VGA DESTINATION:

Output - 1 : Switch 4x VGA sources to #1 Monitor Display

Output - 2 : Switch 4x VGA sources to #2 Monitor Display

Output - 3 : Switch 4x VGA sources to #3 Monitor Display

Output - 4 : Switch 4x VGA sources to #4 Monitor Display


INPUTS: 1 - 4 VGA DEVICE SOURCES

Input - Source 1 : VGA Signal source device #1

Input - Source 2 : VGA Signal source device #2

Input - Source 3 : VGA Signal source device #3

Input - Source 4 : VGA Signal source device #4



HOW TO SETUP IR CODES:

IR TYPE : uPD6121G

POWER ON : 28D7 1CE3

POWER OFF : 28D7 1CE3

OUTPUT#1 / INPUT#1 : 2807 0FF0

OUTPUT#1 / INPUT#2 : 2807 10EF

OUTPUT#1 / INPUT#3 : 2807 12ED

OUTPUT#1 / INPUT#4 : 2807 13EC

OUTPUT#2 / INPUT#1 : 2807 04FB

OUTPUT#2 / INPUT#2 : 2807 05FA

OUTPUT#2 / INPUT#3 : 2807 06F9

OUTPUT#2 / INPUT#4 : 2807 0DF2

OUTPUT#3 / INPUT#1 : 2807 10EF

OUTPUT#3 / INPUT#2 : 2807 00FF

OUTPUT#3 / INPUT#3 : 2807 1BE4

OUTPUT#3 / INPUT#4 : 2807 1BE7

OUTPUT#4 / INPUT#1 : 2807 1FE0

OUTPUT#4 / INPUT#2 : 2807 1AE5

OUTPUT#4 / INPUT#3 : 2807 17E8

OUTPUT#4 / INPUT#4 : 2807 16E9

CONNECTING THE HARDWARE

Please study the panel drawings below and become familiar with the signal input-output, Power requirements plus any controls present.

Before using the switcher, please take the time to make certain that the device you wish to connect to its input is functioning properly in all respects. Verify that the video and audio signals are present and are being displayed properly on a suitable device.

If all is well connect the appropriate cables between the output of the device you wish to distribute to output(s) of the switcher to the various devices you wish to feed a signal to. Lastly, connect the AC to DC adaptor, connect the DC connector to the switcher first and then plug the adaptor into a functional AC outlet.


RS-232 SERIAL INTERFACE

RS-232

The Shinybow switcher can be controlled via the RS-232 serial control port to allow for interfacing to a PC, or similar third party control system.

The serial communication parameters are 9600 baud, 8 bit, No Parity and 1 stop bit - this is often referred to as 9600 8N1. When the unit recognizes a complete command it will perform the requested action - there is no delimiter character required.

The unit does not send out a message when a value is changed from the front panel or by IR control. If the unit needs to be controlled via the front panel in addition to the RS-232 control, you should regularly poll the unit status to ensure the control system accurately reflects the current settings.



RS-232 SERIAL CONNECT

Pin	RS-232	Definition
1	-----	Not used
2	TX	Transmitter
3	RX	Receiver
4	-----	Not used
5	GND	Ground
6	-----	Not used
7	-----	Not used
8	-----	Not used
9	-----	Not used

COMMANDS

To Switch Inputs to Outputs

SBIOXO0Y - Where X is Output Number (1-4) and Y is Input Number (1-4)

Unit will respond with

SBUD0XOY - Where X is Output Number (1-4) and Y is Input Number (1-4)

Example: Send Input 4 to Output 2

SBIO7O02 - Send

SBUD07O2 - Rcvd

MORE STUFF FOR SB-4140

Note: Turning the unit System Power Off over RS-232 will extinguish the LED channel display leaving only the Power switch LED on. The Video and Audio outputs will also mute. While the unit is turned off by RS-232 it will continue to accept and act upon switching commands. For example, if the unit is in the off mode (via RS-232) and you send a command to switch an input to an output, that route will complete and the video and audio will now appear on that channel only. The front panel LED channel display for that particular output will also show the input selected (for that single output channel only). The remaining LED's will remain off and video and audio outputs muted. The unit will still return status and change messages in response to commands sent while in Power Off state. A hard reset command (SBALLRST) will return the unit to normal operation and also unlock the front panel.

POWER OFF MODE

SBSYSMOF - Put system into Standby (Soft Power Off)

SBSYSMON - Bring unit out of Standby (Soft Power On)

Unit will respond with

SBALOFAK - Unit is in Standby

SBALONAK - Unit is no longer in Standby

Example: Put Unit in Standby (Soft Power)

SBSYSMOF - Send

SBALOFAK - Rcvd

FRONT PANEL LOCK

Note: Hard resetting the unit will unlock the Front Panel controls.

SBSYSMLK - When front panel is locked, changes can only be made by RS-232

SBSYSMUK - Front Panel Unlock

Unit will respond with

SBSYSLOK - Front Panel has been Locked

SBSYSULK - Front Panel has been Unlocked

Example: Lock Front Panel Buttons

SBSYSMLK - Send

SBSYSLOK - Rcvd

UNIT RESET

SBALLRST - Reset every output to Input 1

Unit will respond with

SBRSTACK - Unit has reset each Output to Input 1


Example: Reset all outputs to Input 1

SBALLRST - Send

SBRSTACK - Rcvd

TYPICAL APPLICATION

4 x VGA source devices to 4 x VGA Display Matrix Switcher
AB-4140



INSTALLING

CONTROL PORTS:

1. IR REMOTE - IR Remote Controller
2. RS 232 Interface - RS-232 interface system

INPUTS 1 - 4 PORT VGA SOURCE DEVICE SIGNALS:

VIDEO - VGA (RGBHV), connector with HD-15p (D-Sub)

OUTPUT 1 - 4 PORT VGA CONNECT TO DISPLAY MONITOR SIGNALS:

VIDEO - VGA(RGBHV), connector with HD-15p (D-Sub)

AB-4140 SUPPORTS VGA FOUR INPUTS MATRIX TO FOUR SWITCH OUTPUTS
SUPPORT CONTROL IR & RS-232 INTERFACE FROM A PC.

LIMITED WARRANTY

LIMITED WARRANTY

KVMSwitchTech WARRANTY

KVMSwitchTech warrants this product against defects in materials and workman ship for a period of 3 years from the date of purchase.

Should this product, in KVMSwitchTech's opinion, Prove defective within this warranty period, KVMSwitchTech, at its option, will repair this product without charge, to whatever extent it shall deem necessary to restore said product to proper operation condition. This does not extend the warranty period.

This warranty does not apply if the fault has been caused by misuse, improper handling care, electrical or mechanical abuse, and abnormal operating condition or non-KVMSwitchTech authorized modification to the product.

If repairs are necessary under the warranty policy, the original purchaser must return the product to local distributor, freight prepaid.

After repairs are complete, the product will be returned.

REGULATORY COMPLIANCE

The product complies with the relevant standards for CE, FCC and RoHS approval.

The power Adaptor/Supply has been tested for compliance with UL.CSA and CE standards.

TROUBLESHOOTING

If you experience a <no signal> with this switcher or distributor outputs, Þrst make certain that the signal being fed to its inputs is acceptable.

Disconnect the cables from the this switcher or distributor inputs and connect them directly to an appropriate monitoring device, if you do not see or hear a signal the problem may well be he signal source itself. Also check that the AC outlet you have used to power the switcher or distributor is actually providing power as a wall switch often controls an AC outlet.

The second most common problem with this switcher or distributor revolves around the cables, Inspect the cables for loose connectors or cable damage such as crushed cable or cables with cuts or nicks. Replace any cable exhibiting these problems.

You also must use the highest quality cables if you want to achieve the best results. Poor quality cables provide will poor quality signals.

