

# User Manual 17" 4K 3840 x 2160 LCD



Designed and manufactured by Austin Hughes

#### Legal Information

First English printing, July 2018

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

#### Safety Instructions

# Please read all of these instructions carefully before you use the device. Save this manual for future reference.

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labeled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

#### What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - $\hfill\square$  Repair or attempted repair by anyone not authorized by us.
  - □ Any damage of the product due to shipment.
  - □ Removal or installation of the product.
  - $\hfill\square$  Causes external to the product, such as electric power fluctuation or failure.
  - $\hfill\square$  Use of supplies or parts not meeting our specifications.
  - $\Box$  Normal wear and tear.
  - $\hfill\square$  Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

#### **Regulatory Notices Federal Communications Commission (FCC)**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

# Contents

## < Part. 1 > RP-K117

1.1	Package Content	P.1
1.2	Structure Diagram & Dimension	P.1 - 2
1.3	Installation	P.3

# < Part. 2 > Specifications / OSD

2.1	Product Specifications	P.4 - 5
2.2	On-screen Display Operation ( OSD )	P.6 - 8

# < Part. 3 > Options

3.1	3G / HD / SD- <b>SDI</b> Broadcast-grade input	P.10
3.2	HDMI	P.11
3.3	Touchscreen : Resistive 1-point	P.12 - 13
3.4	DC Power : 12V / 24V / 48V / 125V	P.14

# **Before Installation**

- It is very important to mount the equipment in a suitable cabinet or on a stable surface.
- Make sure the place has a good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.

# Unpacking

The equipment comes with the standard parts shown in package content. Check and make sure they are included and in good condition. If anything is missing, or damaged, contact the supplier immediately.

# How To Clean Your LCD Monitor

# A Caution :

- To avoid the risk of electric shock, make sure your hands are dry before unplugging your monitor from or plugging your monitor into an electrical outlet.
- When you clean your monitor, do not press down on the LCD screen. Pressing down on the screen can scratch or damage your display. Pressure damage is not covered under warranty.
- Use only cleansers made specifically for cleaning monitors and monitor screens. Cleansers not made to clean monitors and monitor screens can scratch the LCD display or strip off the finish.
- Do not spray any kind of liquid directly onto the screen or case of your monitor. Spraying liquids directly onto the screen or case can cause damage which is not covered under warranty.
- Do not use paper towels or abrasive pads to clean your monitor. Using an abrasive pad or any wood based paper product such as paper towels can scratch your LCD screen.

# **Cleaning Your Monitor**

To clean your LCD safely, please follow these steps :

- ① Disconnect the power cord.
- ② Gently wipe the surface using a clean, dry microfiber cloth. Use as littl e pressure as possible.

# **Cleaning Tough Marks and Smudges**

To remove tough marks and smudges, please follow these steps :

- ① Disconnect the power cord.
- ② Spray a small amount of non-abrasive cleanser on a microfiber cloth.

Caution : Do not spray or apply any liquids directly onto the monitor. Always apply the solution to your microfiber cloth first, not directly on the parts you are cleaning.

- ③ Gently wipe the surface. Use as little pressure as possible.
- ④ Wait until your monitor is completely dry before plugging it in and powering it up.

# < Part 1 > < 1.1 > Package Content






## RP-K117 unit X1

- Power cord X1
- M6 screw, cage nut & cup washer X8

# < 1.2 > Structure Diagram




# < 1.2 > Dimension


#### **Front View**




**Rear View** 



UNIT : mm 1mm = 0.03937 inch




**Top View** 



Model	Product Dimension	Packing Dimension	Net	Gross
	(W x D x H)	(W x D x H)	Weight	Weight
RP-K117	441.6 x 480 x 44 mm	588 x 758 x 120 mm	11 kg	15 kg
	17.4 x 18.1 x 1.73"	23.1 x 29.8 x 4.7"	24.2 lb	33 lb


# The weight is only for the pure models. It varies with accessories & options such as SDI, HDMI, touchscreen & DC power.

V






Insert the left and right rear mounting brackets into the display drawer.





- Measure the depth of the front and rear mounting rails.
- Align each rear mounting bracket to a suitable length.





#### Complete the installation

Fix the display drawer into the rack.

M6 screw, cage nut & cup washer x 8 are provided.

# < Part 2 >

# < 2.1 > Product Specifications

LCD	Native Resolution	3840 x 2160
Panel	Panel Size ( diagonal )	17.3-inch TFT color LCD
	Brightness ( cd/m <sup>2</sup> )	300
	Contrast Ratio ( typ. )	1000:1
	Colors	16.7 M, 8-bit
	Viewing Angle ( L/R/U/D )	89/89/89
	Response Time (ms)	30
	Dot pitch ( mm )	0.0995
	Display Area (mm)	382.12 x 214.94V
	Surface treatment	Anti-glare
	Surface hardness	3Н
	Backlight Type	LED
	MTBF ( hrs )	20,000

Video	Package	DP 1.2 / HDCP 1.3
	Option	HDMI 2.0 / HDCP 2.2

Power	Power Supply	Range	Auto-sensing 100 to 240VAC, 50 / 60Hz
	Power Consumption	Screen ON	Max. 29W
		Power saving mode	Max. 9W
		Power button OFF	Max. 2W

Compliance	EMC	FCC & CE certified
	Safety	CE / LVD certified
	Environment	RoHS2 & REACH compliant

Environmental	Operating	Temperature	0 to 55°C degree
Conditions		Humidity	20~90%, non-condensing
		Altitude	16,000 ft
	Storage / Non-operating	Temperature	-20 to 60°C degree
		Humidity	5~90%, non-condensing
		Altitude	40,000 ft
		Shock	10G acceleration (11ms duration)
		Vibration	5~500Hz 1G RMS random

Physical Specification	Product (W x D x H)	442 x 480 x 44 mm
Specification		17.4 x 18.9 x 1.73 inch
	Packing (W x D x H)	588 x 758 x 120 mm
		23.1 x 29.8 x 4.7 inch
	Net Weight	11 kgs / 24.2 lbs
	Gross Weight	15 kgs / 33 lbs

Applicable	Display Port Input	PC Signal	3840 x 2160 x 60Hz
Format			1920 x 1080 x 60Hz
			1600 x 1200 x 60Hz
			1360 x 768 x 60Hz
			1280 x 1024 x 60 / 75Hz
			1280 x 768 x 60Hz
			1024 x 768 x 60 / 70 / 75Hz
			800 x 600 x 60 / 72 / 75Hz
			720 x 400 x 70Hz
			640 x 480 x 60 / 72 / 75Hz
		Audio Signal	2ch Linear PCM
	HDMI Input	HDMI 2.0	3840 x 2160 x 60Hz
		HDMI 2.0 / 1.4	3840 x 2160 x 30Hz
			1920 x 1080 x 50 / 60Hz ( 1080p )
			1920 x 1080 x 25 / 30Hz(1080i)
			1280 x 720 x 50 / 60Hz ( 720p )
			720 x 480 x 50 / 60Hz ( 576p / 480p )
		Audio Signal	2ch Linear PCM

\*In some circumstances, if the user connects the LCD to PC via HDMI port or video and audio signals, the LCD may display incorrectly on a full screen. If so, please adjust the display card setting on display size to fix the issue.

# < 2.2 > On-screen Display Operation ( OSD )

Membrane Switch	Function
ம	Turn the monitor on or off
	Display the OSD menu Act as an Enter key to select screen setting options
${\Bbb A}{\Bbb V}{\Bbb A}{\Bbb A}$	Scroll through menu options and adjust the displayed control
Ĵ	Exit the OSD screen Go back to the previous on-screen sub-menu or main menu
ark : All LED touch buttons in <b>W</b> The LED of <b>Power (</b> ) tou	Go back to the previous on-screen sub-menu or main menu

# < 2.3 > On-screen Display Operation ( OSD )

#### 1 Picture

Brightness : Adjust the screen brightness

Contrast	: Adjust the difference between the image background
	( black level ) and the foreground ( white level )
Black level	: Adjust background black level of the screen

- Full Screen / 4:3 / 5:4 / Pixel to Pixel

Eco : Screen in power saving mode

#### **RP-K117**

		PICTURE	DP 3840x2160@60.0Hz
PICTURE	BRIGHTNESS	_	70 >
<b>•••</b>	CONTRAST	_	<b>50</b> >
POSITION	BLACK LEVEL		50 >
COLOR	ECO		STANDARD >
PIP			
MISC	▲/ <del>▼</del> : UP/DOWN	<b>∢/</b> ▶: -,	/+ MENU:EXIT M91KW430STD701LG

	F	POSITION	DP 3840x2	160@60.0F	Iz
PICTURE	PICTURE SIZE		FULL SC	REEN	>
	DP VERSION		DF	1.2	>
COLOR					
OSD SET					
RESET					
PIP					
MISC	▲/♥: UP/DOWN	<b>∢/</b> ▶: −/+	ME M91KW4305	NU:EX TD701L	

#### 3 Color

2

Position

Picture size : Adjust the image size

DP version : Select the DP version

Color temperature	: User / Warm / Cool / 5400k mode and Red / Green / Blue color balance
Sharpness	: Adjust the image from weak to sharp
Hue	: Adjust the screen hue value
Saturation	: Adjust the saturation of the image color
Dynamic Iuminous control	: Control the dynamic brightness

#### COLOR DP 3840x2160@60.0Hz PICTURE COLOR TEMPERATURE USER >←Î→ SHARPNESS <u>50 ></u> POSITION 50 > HUE 9 50 > SATURATION COLOF DYNAMIC LUMINOUS CONTROL OFF OSD SET RESET PIP MENU: EXIT M91KW430STD701LG -▲/▼: UP/DOWN <// >: -/+ MISC

#### (4) OSD Set


Language	: Select the language in which the OSD menu is displayed - English
OSD H-Position	: Align the screen image left or right
OSD V-Position	: Align the screen image up or down
OSD time out	: Adjust the screen timeout
OSD transparency	: Adjust the screen transparency
OSD size	: Adjust the screen size - Normal / Small
OSD rotation	: Rotate the screen - 90° / 180° / 270°

	050	) SET	DP 3840x2160@60.0Hz
	LANGUAGE		
←	OSD H-POSITION		50 >
POSITION	OSD V-POSITION		50 >
	OSD TIME OUT		60 >
COLOR	OSD TRANSPARENCY		0 >
	OSD SIZE		NORMAL >
OSD SET	OSD ROTATION		OFF >
RESET			
PIP			
MISC	▲/▼: UP/DOWN	<b>∢/</b> ▶: <del>-</del> /+	MENU:EXIT M91KW430STD701LG

# < 2.3 > On-screen Display Operation ( OSD )

#### **5** Reset

Reset : Return the adjustment back to factory setting



#### 6 PIP

PIP mode	: Enter into PIP / PBP setting - PIP MODE / PBP 2WIN ( Main screen + 1 sub screen ) / PBP 3WIN ( Main screen + 2 sub screen ) / PBP 4WIN ( Main screen + 3 sub screen ) Select the signal input of each sub screen
PIP size	: Adjust the size of the Sub screen - Small / Medium / Large / Huge
PIP position	: Adjust the position of the Sub screen - Top Left / Top Right / Bottom Left / Bottom Right
Swap	: Swap the input signal of PIP / PBP sub screen

		PIP	DP 3840x2160@60.	0Hz
PICTURE	PIP MODE		PIP MODE	>
-₽-	WINDOW2 INPUT		HDMI2	>
POSITION	WINDOW3 INPUT		HDMI1	>
	WINDOW4 INPUT		DP	
COLOR	PIP SIZE		MEDIUM	
<b>≁</b> ]+→	PIP POSITION		TOP LEFT	>
OSDSET	SWAP			
RESET				
PIP				
MISC	▲/▼: UP/DOWN	<b>∢/</b> ▶: −/+	MENU:E M91KW430STD701	

# 7 MISC


Signal source : Select the signal source - DP / HDMI1 / HDMI2		
Mute	: Turn off the surrounding sound	
Audio in	: Auto / Line in / DP	
Volume	: Adjust the volume of sound	
Sleep mode	: Set the off time - 10 min / 20 min / 30 min / 50 min / 60 min / 120 min / 240 min	

-\-		MISC	DP 3840x2160@60.0Hz	
	SIGNAL SOURCE			
+¦+	MUTE		OFF >	
POSITION	AUDIO IN		AUTO >	
	VOLUME		<u> </u>	
	SLEEP MODE		OFF >	
OSD SET				
RESET				
PIP				
MISC	▲/ <del>▼</del> : UP/DOWN	<b>∢/</b> ▶: -/+	MENU:EXIT M91KW430STD701LG	

#### **Options on Reset page**

Rotation	: Rotate the image in Full screen or 1:1
	- 90° / 180° / 270°

Picture size : Adjust the image size in Full screen or 1:1




# Intentionally Left Blank

# < Part 3 > < 3.1 > Options : 3G / HD / SD-SDI input



Austin Hughes' SDI input is an ideal solution for the broadcastgrade video and high resolution CCTV market.

Designed for use with CyberView displays, a SDI input module can support up to 1080p @60Hz resolution without using additional space or power and it comes standard with a 2-year warranty.



attached 6ft DP cable

يبيني (

÷.

INPUT	3G-SDI IN	BNC x 1 / 0.8Vp-p ( 75 ohm )
	3G-SDI OUT	BNC x 1 / Active through, equalized & relocked

Standard Compliance	Video	SMPTE 425M / 274M / 296M / 125M ITU-R BT.656
	Audio	SMPTE 299M / 272M-C

Compatible Video Format	3G-SDI	1080p 1080p 1080i 720p	@60 / 50Hz, 4:2:2 @30 / 25 / 24Hz, 4:4:4 @60 / 50Hz, 4:4:4 @60 / 50Hz, 4:4:4
	HD-SDI	1080p 1080i 720p	@30 / 25 / 24Hz, 4:2:2 @60 / 50Hz, 4:2:2 @60 / 50Hz, 4:2:2
	SD-SDI	480i	@60Hz, 4:2:2
	ITU-R BT.656	576i	@50Hz, 4:2:2

Compatible Audio Format	3G-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	HD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized Video
	SD-SDI	48kHz, 16 / 20 / 24 bit, 2 CH, Synchronized / Asynchronized Video


Max. Transmission Distance	3G-SDI	150m at 2.97Gb/s	
75 ohm coaxial cable	HD-SDI	250m at 1.485Gb/s	
	SD-SDI	480m at 270Mb/s	

# < 3.2 > Options :

# - HDMI 2.0 (HDCP 2.2)



- (1) In some circumstances, if the user connects the LCD to PC via HDMI port for video and audio signals, the LCD may display incorrectly on a full screen. If so, please adjust the display card setting on display size to fix the issue.
- (2) For the above options, casing depth will be extended from 480mm (18.9") to 530mm (20.9")




# < 3.3 > Options : Touchscreen & driver



## K17" USB Touchscreen Specification

Model	TRB e-Resistive		
Technology	5-Wire Resistive		
Touch Point	Single		
Input Type	Finger or Stylus		
Resolution	2048 x 2048		
Response Speed	15 ms		
Activation Force	≤ 50 g		
Surface Hardness	3H		
Light Transmission	80% ± 3%		
Haze	8% ± 3%		
Durability	10 million touches		
Top Layer	ITO Film		
Bottom Layer	ITO Glass		
Thickness	2.2 ± 0.2 mm		
Connector	USB Type A		
Compatibility	Windows 7 / XP / Vista, Linux		


- USB touchscreen package includes 1 x 6ft USB cable, quick reference guideline and CD disc
- For detailed information, please refer to the attached CD disc
- As the touchscreen unit is not made of toughened glass, please handle it carefully



# < 3.3 > Options : Touchscreen & driver



#### **TRB Driver**




# < 3.4 > Options : DC Power



Model	12V	24V	48V	125V
Input rating				
Input voltage:	12-Volt	24-Volt	48-Volt	110-Volt
Input range:	9 ~ 18V	18 ~ 36V	36 ~ 75V	66 ~ 160V
Input current				
- No load	50 mA	50 mA	50 mA	35 mA
- Full load	4950 mA	2450 mA	1220 mA	460 mA
Output rating				
Output voltage:	12-Volt	12-Volt	12-Volt	12-Volt
Output current:	4.16A	4.16A	4.16A	4.16A
Efficiency	84%	88%	90%	89%

#### **DC** power



(3) Casing depth will be extended from 480mm (18.9") to 530mm (20.9")

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2018 Austin Hughes Electronics Ltd. All rights reserved.